

Montage / Assembly / Montage:

Demontage / Disassembly / Démontage:

| | | | | | | | |
|-----------------|--|-----------------|--------------------------------|---|------------------|----------------------------|-----------------------------------|
| <p>A</p> | <p>1x MQ-41 / MQ-41-L / MQ-21D / MQ-41/3</p> <p>2x HST M10 / HUS4-H 8x55</p> | <p>1</p> | <p>2</p> <p>★click!</p> | <p>3</p> <p>SI-AT-A22 SI-AT-22</p> | <p>max. 5 mm</p> | <p>1</p> | |
| <p>B</p> | <p>Channel I*</p> <p>25 Nm (18 ft-lb)</p> <p>17</p> <p>Channel II*</p> <p>40 Nm (30 ft-lb)</p> <p>17</p> | <p>1</p> | <p>2</p> <p>★click!</p> | <p>3</p> <p>SI-AT-A22 SI-AT-22</p> | <p>0 mm</p> | <p>2</p> <p>90°</p> | |
| | | | | | | | <p>3A</p> <p>3B</p> |

*Channel I: MQ-21.5 / MQ-41-L / MQ-41D-L Channel II: andere MQ Schienen / other MQ Channels / autres rails MQ